

# installation, operation and service instructions

UV condensate pump

## KEEP THESE INSTRUCTIONS NEAR THE PUMP FOR USE OF OPERATOR

### INSTALLATION INSTRUCTIONS

LOCATING PUMP: Install unit in a clean, dry, well ventilated, and drained location for inspection and care, with the cover of the receiver flush with the concrete floor. This unit must be so placed that the condensate will flow into the receiver by gravity, otherwise the returns will be wet, and the system cannot free itself of air.

PIPING: Connect returns to inlet of receiver with a gate valve in each return and with a union or flange joint next to the receiver. Connect discharge of pump to boiler with a union, swing check valve and a gate valve; with the swing check valve as close to the pump as is possible. If discharge pipe is longer than 50 feet, increase piping to the next size larger. Piping must be of correct length to prevent any pipe strain upon the unit.

WIRING: The electrical connections between the motor, float switch and automatic starter (if furnished) are made at the factory. Connect the electric service to the float switch or automatic starter using conduit and wire sizes as required by local power companies. Provide a fused main line switch in motor circuit. CAUTION: The motor is wired and connected at the factory to operate on the voltage specified. If voltage is other than originally specified, consult motor manufacturer's instructions accompanying unit for proper wiring. Where a polyphase motor is furnished with only a float switch, IT WILL BE NECESSARY TO INSTALL A SUITABLE PHASE PROTECTOR SWITCH IN THE MOTOR CIRCUIT TO PREVENT MOTOR BURNOUTS SHOULD A SINGLE-PHASE CONDITION OCCUR.

FUSES: Be sure fuses are installed and comply in size with National Electrical Code recommendations. When a fuse blows out it indicates that something is wrong either in the motor, pump, switch, fuse rating or electric service. Do not replace fuse until the cause for it blowing out has been determined. If a thermal cut-out is used, an element with a maximum tripping current rating 50% greater than motor nameplate current may be selected. Condensate boiler feed pumps are only operating intermittently and therefore it is permissible.

### OPERATING INSTRUCTIONS

CAUTION: New or repaired heating systems should be operated several days with the returns open to sewer until water appears clear, in order to thoroughly flush and clean the lines and prevent clogging of the pump when it is put in operation. This may take from a few days to two weeks.

LUBRICATION: The motor bearings and the pump shaft ball bearing are packed with grease when shipped from the factory, and lubrication is usually not required until after six months of operation. When the motor bearings need lubrication, DO NOT OVER-LUBRICATE TOP BEARINGS OF ANY VERTICAL MOTOR because grease will leak past the grease seals inside of the motor and cause serious damage to the stator windings and armature windings and commutator.

### INSPECTION BEFORE STARTING UNIT FOR THE FIRST TIME:

1. Check motor bearings for lubrication, but do not lubricate unless absolutely necessary – see preceding paragraph regarding instructions.
2. Turn shaft and see that it rotates freely by hand. Failure of shaft to turn freely may be caused by packing glands drawn too tightly, motor bearings too tight or not lubricated or dirt clogging pump or becoming lodged in motor.
3. Be sure current characteristics of voltage, phase and frequency on motor nameplate are the same as the service available. Also be sure that wires are connected to motor as per motor manufacturer's instructions for voltage and phase used, and that the correct size fuses and thermal cut-outs are installed.

4. Be sure that piping connections have been made as per instructions, and that the air vent pipe leading from the receiver is open to atmosphere.
5. Be sure that the engineering characteristics of the complete pumping unit are identical to the capacity, discharge pressure, and other requirements of the heating system.
6. Be sure that the float in the receiver is free to operate float switch.

**STARTING:** Open valves in discharge and return lines, close valve on drains and throw in fused knife switch. If an automatic starter with selector switch is installed, be sure selector switch is in "Automatic" position.

**AFTER STARTING:**

1. With vent pipe open to atmosphere, air and steam can escape as fast as condensation flows into the receiver. If vent is restricted or clogged, receiver will not fill.
2. Be sure pump and motor rotate in proper direction. Correct direction of rotation is clockwise when looking at top of motor. If rotation is reversed, the trouble may be corrected in polyphase motors by simply reversing any pair of leads. If the motor is single phase, adjust the brush settings. (See motor instruction card.) If motor is D.C., reverse armature leads.
3. Be sure bearings of the motor do not overheat.
4. Be sure float switch closes and opens properly as receiver fills and is emptied by the pump. Normally this need not be touched. If required however, refer to float switch instruction card.
5. Be sure all connections are tight.
6. Observe operation of unit closely for approximately three hours after starting and at regular intervals for ten days. A new unit is frequently stiff, and bearings are tight, and therefore should be watched to note performance.



**CARE**

1. **INSPECTION:** To ensure the best operation of the unit, make weekly systematic inspections.
2. **CLEANLINESS:** Keep the interior and exterior of motor and automatic switches free from moisture, oil and dirt. When necessary, blow out the interiors with compressed air or a bellows. Occasionally drain and flush receiver to remove sediment and scale, frequency depending upon operating conditions.
3. **BEARINGS:** Prevent excessive heating and wear of bearings by proper lubrication at regular intervals, depending upon the type of pump service and cleanliness of location. Avoid over lubrication, which also causes bearings to heat up and produce excessive wear. When bearings are worn and unit is noisy, replace immediately with new bearings so as not to injure the other rotating parts.
4. **AUTOMATIC SWITCHES:** Occasionally examine contacts of automatic switches and see that they make a full firm contact and break the circuit quickly. See that all terminal connections are tight.
5. **STUFFING BOXES:** Keep packing glands just tight enough to allow a slight drip for lubrication, but not too tight as to bind the pump shaft. Tighten opposite nuts evenly. After tightening nuts turn shaft by hand; if it binds, loosen nuts slightly. Use only packing as furnished in pump or as recommended by Skidmore.
6. **SHUTTING DOWN:** At the end of the heating season open main line switch, close valves on return and discharge, and drain receiver and pump. Cover motor and automatic switches to protect them against dirt, etc.
7. **CAUTION:** Never run pump when it is empty or expose it to freezing temperatures when filled with water.

**ORDERING PARTS**


When ordering parts, always furnish pump serial number indicated on nameplate, which may be attached to receiver, pump or base depending upon convenience. State quantity, name or description and part number if a casting.

# PUMP ASSEMBLY




Motor Bracket Assembly

Shaft Coupling




Volute Assembly




Discharge Line


## FLOAT ASSEMBLY




Upper Linkage (Inside Cover)



Float Ball & Lower Linkage




Upper Linkage (Outside Cover)



Float Switch and Mounting Hardware

## TANK COVER ASSEMBLY



### PARTS LIST

|    |   |    |                               |
|----|---|----|-------------------------------|
| 1  | Receiver                                  | 39 | Tank Cover Weld Stud          |
| 2  | Motor Bracket                             | 40 | Tank Cover Large Weld Stud    |
| 3A | Motor Coupling                            | 41 | Tank Cover Weldolet           |
| 3B | Shaft Coupling                            | 42 | Tank Cover                    |
| 4  | Coupling Insert                           | 43 | Float Ball                    |
| 5  | Coupling Key                              | 44 | Float Ball Rod                |
| 6  | Shaft Bearing                             | 45 | Float Ball Link               |
| 7  | Packing Gland                             | 46 | Float Push Rod Lower Link     |
| 8  | Packing Gland Retaining Washer            | 47 | Float Push Rod Lever Support  |
| 9  | Shaft Packing Material                    | 48 | Float Switch Push Rod         |
| 10 | Shaft                                     | 49 | Float Pipe Support            |
| 11 | Pump Assembly Tank Cover                  | 50 | Float Key Support             |
| 12 | Shaft Housing                             | 51 | Float Upper Lever Link        |
| 13 | Discharge Valve                           | 52 | Float Upper Push Rod Link     |
| 14 | Discharge Pipe Nut                        | 53 | Float Linkage Pin             |
| 15 | Discharge Pipe Gasket                     | 54 | Float Rivet Pin               |
| 16 | Discharge Pipe                            | 55 | Float Switch Mounting Bracket |
| 17 | Impeller                                  | 56 | Float Switch Gasket           |
| 18 | Volute Adapter                            | 57 | Float UV Link                 |
| 19 | Volute Gasket                             | 58 | Float Switch UV Lever         |
| 20 | Volute                                    | 59 | Float Switch                  |
| 21 | Volute Discharge Gasket                   | 60 | Float Bushing and Stuffing    |
| 22 | Volute Discharge Elbow                    | 61 | Float Operating Shaft         |
| 23 | Shaft Bushing                             | 62 | Float Cover Plate             |
| 24 | Impeller Key                              | 63 | Float Support Rod Nut         |
| 25 | Impeller Retaining Washer                 | 64 | Float Lever Set Screw         |
| 26 | Impeller Bolt                             | 65 | Float Push Rod Nut            |
| 27 | Volute Discharge Bolt                     | 66 | Float Pipe Support Nut        |
| 28 | Volute Adapter Bolt                       | 67 | Float Switch Mounting Bolt    |
| 29 | Packing Gland Bolt                        | 68 | Float Switch Mounting Washer  |
| 30 | Motor Bolt                                | 69 | Float Switch Mounting Nut     |
| 31 | Volute Washer / Lockwasher                | 70 | Float Linkage Long Rivet      |
| 32 | Volute Nut                                | 71 | Float Linkage Rivet           |
| 33 | Volute Stud                               | 72 | Float Lever Pin               |
| 34 | Motor                                     | 73 | Float Operating Rod Collar    |
| 35 | Tank Cover to Receiver Flange Bolt        | 74 | Float Operating Rod           |
| 36 | Tank Cover to Receiver Washer             | 75 | Float Switch Arm              |
| 37 | Tank Cover to Receiver Nut                | 76 | Float Switch Base             |
| 38 | Tank Cover to Motor Bracket and Float Nut |    |                               |

